

SPARE PARTS LIST

MODEL NO. EW1050H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	135562-0	CYLINDER BLOCK ASSEMBLY INC. 2,41	1	
002	922217-4	HEX. SOCKET HEAD BOLT M5X14	8	
003	424530-1	OIL CASE GUARD	2	
004	450565-6	OIL GAUGE	1	
005	424100-6	GASKET	1	
006	318442-7	OIL CASE	1	
007	162276-8	CASE GASKET	1	
008	922217-4	HEX. SOCKET HEAD BOLT M5X14	4	
009	140023-7	ROCKER COVER COMPLETE	1	
010	162275-0	ROCKER COVER GASKET	1	
011	922222-1	HEX. SOCKET HEAD BOLT M5X16	3	
012	162274-2	CAM GEAR COVER GASKET	1	
013	318443-5	CAM GEAR COVER	1	
014	922217-4	HEX. SOCKET HEAD BOLT M5X14	3	
015	346083-9	LEAD VALVE	1	
016	318440-1	RETAINER PLATE	1	
017	922112-8	HEX. SOCKET HEAD BOLT M4X10	1	
018	126299-0	CRANK SHAFT ASSEMBLY	1	
019	213147-3	OIL SEAL 12	1	
020	213148-1	OIL SEAL 10	1	
021	267400-9	FLAT WASHER 23	1	
022	265577-4	HEX HEAD BOLT M6X16	1	
023	254040-2	WOODRUFF KEY 3	1	
024	257781-9	PISTON PIN	1	
025	318441-9	PISTON	1	
026	196595-0	PISTON RING SET	1	
027	233976-8	CLIP	2	
028	326223-5	SHAFT	1	
029	911323-0	PAN HEAD SCREW M6X16	2	
030	125552-1	CAM GEAR ASSEMBLY	1	
031	268238-5	PIN 5	1	
032	313169-4	CAM LIFTER	2	
033	268239-3	PIN 4	1	
034	234108-0	COMPRESSION SPRING 9	2	
035	325668-4	SPRING RETAINER	2	
036	326367-1	INTAKE VALVE	1	
037	326366-3	EXHAUST VALVE	1	
038	256200-2	PIN 5	1	
039	256865-0	ROD 2.5	2	
040	125554-7	ROCKER ARM ASSEMBLY	2	
041	424200-2	SPACER	2	
042	168469-5	EXHAUST MUFFLER	1	
043	324980-9	SPARK ARRESTER	1	
044	345915-7	MUFFLER COVER	1	
045	345916-5	MUFFLER GASKET	1	
046	265184-3	+TRUSS HEAD SCREW M5X5	1	
047	266440-4	HEX SOCKET HEAD BOLT M5X40	2	
048	450559-1	INSULATOR	1	
049	413120-5	INSULATOR GASKET	1	
050	413121-3	CARBURETOR GASKET	1	
054	450562-2	CLAMP	1	
055	325934-9	ADJUST SCREW	1	
058	345918-1	HOSE CLAMP	1	
059	422041-0	BREATHER PIPE	1	
060	422042-8	PIPE	1	
061	125468-0	CLEANER PLATE ASSEMBLY INC. 62-69	1	
062	451925-5	CHOKE LEVER	1	
063	213540-1	O RING 15	1	
064	424316-3	CHECK VALVE	1	

SPARE PARTS LIST

MODEL NO. EW1050H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
065	213539-6	O RING 14	1	
066	451924-7	CHECK VALVE PLATE	1	
067	424315-5	CHECK VALVE	1	
068	168577-2	SEPARATOR GASKET	1	
069	168576-4	SEPARATOR PLATE	1	
070	911218-7	PAN HEAD SCREW M5X14	1	
071	450561-4	AIR CLEANER COVER	1	
072	443141-3	AIR CLEANER ELEMENT	1	
073	450560-6	CHOKE PLATE	1	
074	423376-2	GASKET	1	
075	345919-9	PLATE	1	
076	265188-5	+PAN HEAD SCREW M5X68	2	
078	141766-4	BLOWER HOUSING COMPLETE	1	
082	922223-9	H.S.H.BOLT M5X16 WITH WR	3	
084	922213-2	H.S.H.BOLT M5X12 WITH WR	1	
085	922228-9	H.S.H.BOLT M5X18 WITH WR	2	
086	450564-8	CYLINDER COVER	1	
087	452144-6	PLUG COVER	1	
088	911213-7	PAN HEAD SCREW M5X12	2	
089	911128-8	PAN HEAD SCREW M4X16	2	
090	911128-8	PAN HEAD SCREW M4X16	2	
091	195146-6	RECOIL STARTER SET INC. 92-99	1	
092	232258-5	SPIRAL SPRING	1	
093	451937-8	REEL	1	
094	444019-3	STARTER ROPE	1	
095	424319-7	STARTER KNOB	1	
096	325923-4	SWING ARM	1	
097	451938-6	COLLAR	1	
098	168483-1	PULLEY	1	
099	266585-8	TAPPING SCREW 5X12	1	
100	450566-4	FUEL TANK	1	
101	125472-9	FUEL TANK CAP ASSEMBLY INC. 167	1	
102	163447-0	GASOLINE FILTER	1	
103	168472-6	TUBE COMPLETE	1	
104	345920-4	HOSE CLAMP	1	
105	424102-2	PLATE	1	
106	424103-0	PLATE	1	
107	424104-8	DAMPER	1	
108	168781-3	CARBURETOR INC. 110,113-119,121-127	1	
109	352010-6	INLET SCREEN	1	
110	346270-0	PRIMER PUMP COVER	1	
113	442155-9	PUMP GASKET	1	
114	442154-1	METERING DIAPHRAGM GASKET	1	
115	168575-6	PUMP DIAPHRAGM	1	
116	168574-8	METERING DIAPHRAGM	1	
117	266582-4	TAPPING SCREW 3X24	4	
118	234183-6	CONICAL COMPRESSION SPRING 5-9	1	
119	WJ00096364	SCREW M3X8 WITH WASHER	2	
121	325922-6	SWIVEL	1	
122	257964-1	STOP RING E-3	1	
123	413140-9	WASHER	1	
124	140437-0	PUMP BODY	1	
125	140438-8	AIR PURGE BODY	1	
126	424314-7	PRIMER PUMP	1	
127	213538-8	O RING 2	1	
128	318702-7	FLYWHEEL	1	
129	168501-5	IGNITION COIL	1	
130	266602-4	HEX. SOCKET HEAD BOLT M4X20	2	

SPARE PARTS LIST

MODEL NO. EW1050H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
131	126240-3	STOP SWITCH ASSEMBLY	1	
132	324891-8	PLUG CAP SPRING	1	
133	168401-9	SPARK PLUG	1	
134	424105-6	PLUG CAP	1	
161	324961-3	INTAKE PIPE	1	
162	213078-6	O-RING 10	1	
163	424201-0	CHECK VALVE	2	
164	806902-6	GAS EMISSION APPROVAL LABEL	1	
165	819430-2	CAUTION TAG	1	
166	897794-4	SERIAL NO. LABEL	1	
167	140436-2	STRAP COMPLETE	1	
168	ME08121070	REFUELING HANDLE GROUP	1	
169	ME00204835	SHELF GROUP	1	
170	ME01676311	RUBBER FEET	4	
171	ME08121002	PUMP FRAME	1	
172	ME01676313	HEXAGON BOLT	4	
173	ME00200115	WAD	4	
174	ME01676314	GASKET	4	
175	ME01676315	O-RING	4	
176	ME00200486	MECHANICAL OIL SEAL	1	
177	ME08121003	IMPELLER	1	
178	ME08121004	VOLUTE	1	
179	ME01676319	SEAL RING	1	
180	ME01676320	O-RING	1	
181	ME08121005	PUMP CASING	1	
182	ME08121006	HANDLE	1	
183	ME00200116	HEXAGON BOLT	4	
184	ME00200117	WAD	4	
185	ME01676323	HEXAGON NUT	4	
186	ME00200091	FLAT GASKET	4	
187	ME08121007	VALVE	1	
188	ME08121008	TUBE JOINT BOLT	1	
189	ME00200011	HEXAGON BOLT	3	
190	ME01676327	TUBE JOINT CORE	2	
191	ME08121009	LOCKNUT	2	
192	ME08121044	SEAL RING	2	
193	ME01689268	STRAINER GROUP	1	
194	ME01676330	HOOP	3	
195	ME01676331	WATER BLOCK	2	
196	ME01676329	O-RING	2	
197	ME01676333	GASKET	99	
198	ME01676334	GASKET	99	
199	ME08121010	REFUELING WINDING	1	
200	ME01676336	SUCTION PIPE	1	
201	ME08121001	NOTE LABEL	1	
202	ME08121012	NOTE LABEL	1	
203	ME08121030	NOTE LABEL	1	
204	ME08121035	NOTE LABEL	1	
205	ME03333192	NOTE LABEL	1	
A01	ME08121017	SOCKET WRENCH	1	
A02	ME08121040	RAPID JOINT GROUP INC. A03,A04	1	
A03	ME08121044	SEAL RING	1	
A04	ME08121045	SEAL RING	1	
A05	ME08121051	JOINT CORE INC. A06,A07	1	
A06	ME08121052	CONNECTOR NUT	1	
A07	ME08121044	SEAL RING	1	
A08	ME08121053	HOOP	1	
A09	ME08122060	THE PIPE GROUP INC. A10,A11	1	


SPARE PARTS LIST

MODEL NO. EW1050H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
A10	ME08121044	SEAL RING	1	
A11	ME08122068	O-RING	1	
A12	ME08122030	GUN GROUP	1	
		INC. A13-A15		
A13	ME08122032	GUN GLOVES	1	
A14	ME08122034	ROUND HEAD SCREW	1	
A15	ME08122035	O-RING	1	
A16	ME08121060	CROSS OVER SUB	1	
A17	ME08121044	SEAL RING	1	
A18	ME08121080	OILER	1	

SERVICE DRAWING

MODEL NO. EW1050H



SERVICE DRAWING

MODEL NO. EW1050H

