

SPARE PARTS LIST

MODEL NO. 9527NB

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	266173-1	TAPPING SCREW 5X30	4	
002	415491-6	PIN CAP	1	
003	233072-2	COMPRESSION SPRING 8	1	
004	256437-1	PIN 4	1	
005	961002-0	RETAINING RING S-6	1	
006	226748-8	SPIRAL BEVEL GEAR 10	1	
007	211088-7	BALL BEARING 6000DDW	1	
008	316807-7	GEAR HOUSING COVER	1	
009	241891-2	FAN 57	1	
010	415971-2	BAFFLE PLATE	1	
011	517308-0	ARMATURE ASS'Y 220V INC. 9,12,13	1	
012	681638-6	INSULATING WASHER	1	
013	211012-0	BALL BEARING 606ZZ	1	
014	521628-6	FIELD ASS'Y 220/240V	1	
015	266007-8	TAPPING SCREW BIND PT 3X10	2	
016	266034-5	TAPPING SCREW CT 4X16	4	
017	415952-6	SWITCH KNOB	1	
018	858485-2	NAME PLATE 9527NB	1	
019	417352-6	SWITCH LEVER	1	
020	159866-6	MOTOR HOUSING COMPLETE	1	
021	682502-4	CORD GUARD 8-85	1	
022	233285-5	COMPRESSION SPRING 4	1	
023	666066-6	POWER SUPPLY CORD 1.0-2-2.5	1	
024	415955-0	REAR COVER	1	
025	265995-6	TAPPING SCREW 4X18	2	
026	654532-5	TERMINAL BLOCK 1P	1	
027	687063-9	CORD CLAMP	1	
028	265995-6	TAPPING SCREW 4X18	2	
029	651433-8	SWITCH ST115A-31	1	
030	191940-4	CARBON BRUSH CB-411	1	
031	643928-5	BRUSH HOLDER CAP	2	
032	819063-3	MAKITA LABEL	1	
033	224554-5	LOCK NUT 14-45	1	
034	224415-9	INNER FLANGE 42	1	
035	152522-7	SPINDLE COMPLETE	1	
036	165053-7	WHEEL COVER	1	
037	251391-4	PAN HEAD SCREW M5X16	1	
038	316800-1	BEARING BOX	1	
039	211129-9	BALL BEARING 6201DDW	1	
040	962151-6	RETAINING RING R-32	1	
041	226749-6	SPIRAL BEVEL GEAR 36	1	
042	159874-7	GEAR HOUSING COMPLETE	1	
043	645147-9	NOISE SUPPRESSOR	1	
A01	153489-2	GRIP 36 COMPLETE	1	
A02	782407-9	LOCK NUT WRENCH 35	1	
B01	183915-7	SPIRAL BEVEL GEAR SET INC. 6,41	1	
E04	183981-4	STEEL CASE SET	1	

SERVICE DRAWING

MODEL NO. 9527NB

